

### Display and display keys

Contains several lines and pages providing information on calls and the functions accessible via the 6 keys associated with the words on the screen.



**Transfer icon:** pressing the key next to this icon allows you to program or change the transfer function.

**Headset connected.**



**Appointment programmed.**

**Silent mode activated.**



**Telephone locked.**

**Display keys:** pressing a display key activates the function shown associated with it on the screen.

### Navigation



**OK key:** used to validate your choices and options while programming or configuring.



**Left-right navigator:** used to move from one page to another.



**Up-down navigator:** used to scroll through the content of a page.



**Back/Exit key:** to return to previous menu (short press) or return to first screen (long press); during a conversation, provides access to welcome screens (Menu, Info, ...) and to return to the conversation icon screens.

### Welcome screens



**Menu page:** contains all functions and applications accessible via the keys associated with the words on the screen.

**Perso page:** contains call line keys (allowing supervision of calls) and programmable call keys.

**Info page:** contains information on the telephone and the status of its functions: name, telephone number, number of messages, activation of transfer function, appointment reminder, etc.


### Call display




**Incoming call.**



**Call in progress or outgoing call.**



**Call on hold\*.**



**Left-right navigator:** used to check calls.

If you get two calls at the same time, you can switch from one call to the other by pressing the display key associated with each call.

### Function keys and programmable keys



**Guide key:** used to obtain information on functions of the "menu" page and to program key of the "perso" page.



**Messaging key to access various mail services:** if the key flashes, a new voice message or a new text message has been received.



**"Redial" key:** to access the "Redial" function.



**Programmable key (F1 and F2 keys):** lit when the function associated with the key is activated.

## Customize your terminal

The customization functions of the telephone are accessed from the **Menu** page.

### Modifying your personal code

Menu



reach the "menu" page



### Lock / unlock your telephone

Menu



reach the "menu" page

depending the displayed informations, enter your password or confirm



### Adjusting the audio functions

Menu



reach the "menu" page



### Adjusting screen brightness

Menu



reach the "menu" page



increase or decrease the contrast

### Audio keys



**Hang-up key:** to terminate a call.



**Hands-free/Loudspeaker Key:** to make or answer a call without lifting the receiver.

- Lit in hands-free mode or headset mode (short press).
- Flashing in loudspeaker mode (long press).

#### Intercom/Mute key



- During a conversation: press this key so that your correspondent can no longer hear you.
- Terminal idle: press this key to answer calls automatically without picking up the receiver.



**To adjust the loudspeaker or handset volume up or down.**

### Extension unit



An extension unit can be fitted to your telephone. This provides additional keys which can be configured as function keys, line keys, call keys, etc.

**To affix labels:** push the holding strip of the unit backwards to you and lift it. Install the label under the keypad, in the housing designed for, and place the keypad back into position.

## Using your telephone

### Identify the terminal you are on

Info

The number of your telephone is displayed on the "Info" page.



Access the **Info** page using the navigator.

### Making a call



lift the receiver

OR



hands free

OR



programmed line key

OR



dial directly the number for your call



To make an external call, dial the outside line access code before dialling your correspondent's number.

### Receiving a call




lift the receiver

OR



hands free

OR



press the key next to the "incoming call" icon




### Redialling



last number redial

### Make a call-back request to a busy number

the number you are calling is busy



hang up

### Voice message service

#### Consulting your voice mailbox

If the key flashes, a new voice message or a new text message has been received.



follow informations displayed on the screen

press the key next to "consult voice or text message"

## Divert your calls to another number

### Divert your calls to another number



press the key associated with the type of diversion required (immediate, if busy, if no reply etc.)



dial the destination number



press the ok key if programming is not automatically recorded

### Diverting calls to your voice mailbox



press the key associated with "divert to voice mailbox"



press the ok key if programming is not automatically recorded

### When you return, cancel all diversions



if necessary, confirm cancellation of the diversion

press the key next to "cancel or deactivate the diversion"

## Directory

### Using call by name



enter the first letters of the name



select the name from the displayed list



make the call



OR



select the name from the displayed list



make the call

### Program your call keys

perso



OR



follow informations displayed on the screen

press a call key (not programmed) or a programmable key (f1 or f2)

### Make calls via your programmed call keys

perso



find the correspondent you want to call from the programmed call keys




call the chosen correspondent

## During a conversation

### Sending DTMF signals

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine. The function is automatically cancelled when you hang up.



during a conversation



OR



to activate

### Calling a second person during a conversation

During a conversation, to call a second person.



OR



the first call is on hold

dial directly the number for your call

dial

### Transferring a call

During a conversation, to transfer the call to another number:



number to be called

### Three-way conference

During a conversation, a second call is on hold.



three-way conference



cancel conference and return to first correspondent



hang up on all correspondent

## Guarantee and clauses

This document describes the services available on telephones Alcatel 4028-4029 connected to an Alcatel OmniPCX Office or Alcatel OmniPCX Enterprise system. For more information, please consult the User Guide for your 4028 (IP set) or 4029 (digital set). Contact your installer.  
Warning: never place your telephone in contact with water. To clean your telephone, you may however use a damp soft cloth. Never use solvents (trichlorethylene, acetone, etc.) which may damage the plastic parts of your telephone. Never spray it with cleaning products.  
The ear piece and microphone area of the handset may attract metallic objects that may be dangerous for the ear.

The wording is not contractual and may be subject to change. Some functions of your telephone are controlled by a software key and the configuration of the unit.

EC countries: we, **Alcatel Business Systems**, declare that the Alcatel 4028 and 4029 products comply with the essential demands of Directive 1999/5/CE of the European Parliament and Council.



Collection of these products at the end of their product life must be done selectively. Alcatel Business Systems, in keeping with its policy of constant product improvement for the customer, reserves the right to modify product specifications without prior notice. Copyright © Alcatel Business Systems. 2006. All rights reserved.



3GV19005BSAA010605